



SPECIALISED
COVERS

To Protect & Preserve

PRODUCT MANUAL & FITTING GUIDE



ROOF COVER

TYPE: TAILORED FIT

EACH ROOF COVER COMES WITH THE FOLLOWING:

- Storage bag
- Straps to secure round the steadies and A-frame
- 1 year manufacturing warranty
- 3-year Fabric Guarantee

FEATURES & BENEFITS OF THE ROOF COVER:

- 100% waterproof & breathable fabric
- UV protected fabric
- UK manufacture & support
- Secures directly into the awning channel
- Fully length zips on both sides are used to secure the cover

IMPORTANT: CARE INSTRUCTIONS

Before you fit your new ROOF COVER please ensure the top and front of your caravan is clean and that dirt is not trapped between the cover and the caravan which could potentially cause damage.

When cleaning the ROOF COVER we advise, for best results and for the long term benefit of the product, that you use a damp cloth in warm, mild soapy water. Allow to dry naturally.

DO NOT CLEAN IN ANY WASHING MACHINE OR DRY CLEAN.



◀ SCAN HERE TO VIEW OUR
FITTING GUIDE VIDEO

NEED HELP? CALL OUR EXPERTS FOR ASSISTANCE

Office hours: Mon – Fri 9am – 5pm, Sat – Sun CLOSED

T: 01943 864 646

E: info@specialisedcovers.com

specialisedcovers.com



SPECIALISED
COVERS

**MADE IN
BRITAIN**

PRODUCT MANUAL & FITTING GUIDE

BEFORE FITTING YOUR COVER PLEASE NOTE

Take a moment to familiarise yourself with the product.

- When fitting your Roof cover please ensure it is clean. Always put your cover on a clean vehicle, this will make sure there is no dirt trapped between the cover and the vehicle, ensuring it will be pristine condition when you come to uncover it.
- The roof cover fits directly into the awning channels on either side and is secured with full length zips running front to back. This makes the cover lighter and easier to fit than our full storage covers. You do still need to lift the full roof panel up and over the caravan which we recommend using a ladder or step to help reach the roof line.
- To aid fitting we recommend that the cover is folded over the A-frame in a concertina way to allow the smooth fitting over the caravan. The cover will be packed in this way when you receive it with the zips undone and should be refolded in this way when the cover is returned to its bag. The zips are best undone as when attached to the cover it makes it harder to fold back into the bag due to the stiffness of the awning tape.
- Two person fitting is recommended.
- It is important to remember the cover is held on through the awning channels and clips, no further adhesion materials or methods are necessary.
- To keep your roof cover clean, sponge down with mild soapy water.
- The cover slots into the awning channels on either side of the caravan and is then zipped on. You also have straps to secure around the steadies and A-frame to ensure the cover is secure.
- The roof cover is designed for storage use only and should not be used whilst towing your caravan. Specialised Covers cannot be held responsible for cover misuse, the roof cover has not been designed to cope with the strains of travel or has allowances for the caravans running lights.

IMPORTANT NOTICE

Whilst the fabric used to manufacture your cover does not tear easily, any sharp objects may cause damage and it is important that any sharp edges such as gutter ends (top and bottom of van) are protected.

Some makes of caravan have metal strips along the roof with screw-caps/rivets which stand proud. Please check before fitting the cover. As a guide, anything which feels sharp to the hand must be protected (bubble-wrap enclosed). If your caravan is fitted with a status aerial the centre spike must be removed before fitting.

NEED HELP? CALL OUR EXPERTS FOR ASSISTANCE

Office hours: Mon – Fri 9am – 5pm, Sat – Sun CLOSED



FITTING THE COVER

1

Remove the cover and straps from the bag placing the open cover over the A-frame.

The cover should be folded like a concertina to allow it to lift smoothly over the caravan. The zips should also be fully unzipped when removed from the bag on both sides.



2

Ensure the covers a frame cut out is located at the bottom of the cover when placed onto the A-frame.

This means that the rear section of the cover will be at the top making it easier to feed over the caravan.



3

Feed the awning tape into each of the awning channels on both sides of the caravan leaving the folded section of the cover on the a-frame. Feed the awning tape all the way to the back of the caravan.

If possible secure the A-frame cut out with the strap to prevent the cover from moving further.



4

Once the awning tape is in on both sides secure the rear leg steady straps to the rear clips which should currently be at the front of the caravan and are located on the rear of the cover.

The straps are to help you pull the cover along the roof with the use of a step or ladders.



5

Once the leg steady straps are attached walk down either side of the caravan lifting the top panel as you go down. Please be aware of aerials and other items that are on your roof, as the cover will need to be lifted over these.

We recommend you use a step or ladders to help with fitting and to reach the roof line.



6

When you reach the back of the caravan loosely fasten the leg steady straps around the legs to prevent the cover from moving whilst you secure the zips.

These can be tightened later.



Once the top panel is in place starting at the front of the caravan pull the zip along the roof line. This is again easier with ladders or a step and we have added an additional strap to the zip pull to support moving it along the caravan.

You may find the fabric under the zip gets caught when you move along the caravan. This simply needs to be tucked in as you work along the zip and the extra fabric is there to protect your caravan from the zip so cannot be removed.



When both sides are fully zipped up the leg steady straps can then be added. The supplied straps should be clipped into the front middle buckle, threaded through any section of the leg then clipped in the buckle closest to the awning rail.

Any excess webbing strap can be removed, please do not over tighten the leg steady straps.



Ensure that the A-frame strap is secured and any excess webbing is removed. The rear leg steadies can be adjusted at this point if not done previously. Check the zip covers are over the ends of the zips and you are happy the cover is secured.

Your roof cover is now fitted and ready to protect your caravan from the elements.



To remove the cover undo the leg steady straps from all four corners and unzip the cover on both sides.

Pull the cover from the front of the caravan creating a concertina fold over the A-frame.



Once you have the folded cover and the awning strips on the A-frame, leave the cover unzipped.

Move the cover to a flat surface and fold trying to keep the awning tape inside of the cover as best as possible.



Packing it in this way will help you when you come to refit the cover at a later date.

Then simply place the cover back in its storage bag.