



SPECIALISED  
COVERS

To Protect & Preserve

## PRODUCT MANUAL & FITTING GUIDE



NEW  
WINDOW  
ACCESS

## tow pro +

TYPE: TAILORED FIT

### EACH TOW PRO + COMES WITH THE FOLLOWING:

- Customised colour panels
- QUICK ZIP SYSTEM to aid fitting
- 2 CLEAR EYES for caravan lights
- ELASTIC WINGS to aid cover tension
- Storage bag
- Easy grab handle access
- Locker box access
- Window access

### FEATURES & BENEFITS OF THE TOW PRO:

- 100% waterproof & breathable fabric
- UV protected fabric
- Protects from stone chips & cracked windows
- Prevents road dirt & exhaust fume debris build up
- Protects from insect residue

### IMPORTANT

Before you fit your new TOW PRO + please ensure the front of your caravan is clean and that dirt is not trapped between the cover and the caravan which could potentially cause damage.

When cleaning the TOW PRO + we advise, for best results and for the long term benefit of the product, that you use a damp cloth in warm, mild soapy water. Allow to dry naturally.

DO NOT CLEAN IN ANY WASHING MACHINE OR DRY CLEAN.

### WARRANTY

- 1 year manufacturing warranty
- 1 year fabric warranty
- UK manufacture and support

NEED HELP? CALL OUR EXPERTS FOR ASSISTANCE

Office hours: Mon – Fri 9am – 5pm, Sat – Sun CLOSED

T: 01943 864 646

E: [info@specialisedcovers.com](mailto:info@specialisedcovers.com)

W: [specialisedcovers.com](http://specialisedcovers.com)



## BEFORE FITTING YOUR COVER PLEASE NOTE

Take a moment to familiarise yourself with the product.

- The cover does require two awning channels and an opening on both sides to fit the cover.
- When fitting your Tow Pro + the front of the caravan must be clean.
- Please note; if your caravan does not have a bottom awning access your cover should be fitted from the top and worked down the awning channel.
- Two person fitting is recommended but the product has been designed so it can be fitted by one person easily.
- It is important to remember the cover is held on through the awning channels and clips, no further adhesion materials or methods are necessary.
- If your caravan does not have an awning stopper built in we will supply them with the cover. These need to be fitted into the channel at the base where the cover naturally finishes.

### PLEASE NOTE

The Tow Pro cover range is designed specifically to protect your caravan whilst being towed. It is **not** intended to be used as a storage cover or to be left affixed to the caravan whilst it is being stored. Please remove this cover once you have reached your destination.



Older Coachman covers also had a additional fixing point which has now been removed. This was a large flap located at the top of the cover, which hooked over the Coachman sign located above the front window. If your cover does not have it, it has been removed from the design. Please see image for reference.

The Tow Pro + comes with an accessory pack that includes an elasticated tension strap with velcro tabs either end, and fixing clips to help stabilise the cover when utilising its window access function. This feature should only be used when the caravan is stationary.

## FITTING THE COVER



### STEP 1

Place the Tow Pro + across the front of your caravan sitting across the A-frame. On the near side of the caravan and from the bottom feed the awning tape into the channel. Slowly begin to slide the awning tape up the channel until the full length is fitted.



### STEP 2

Walk around to the offside of the caravan and undo the full height zip. From the bottom feed the awning tape into the channel feeding it to the top. Once fully in the channel zip up the open section. Ensure the cut away A-frame section sits neatly over the A-frame.



### STEP 3

Ensure that the cover sits straight and adjust accordingly so that the caravan's lights are clearly visible through the Clear Eyes. If required ensure the awning stoppers have been fitted at this point.



### STEP 4

The elasticated Quick Fit Clips are designed to clip under the lip of the caravan as shown, and are designed to create tension and prevent dirt getting underneath the cover.



### STEP 5

Ensure that all of the cover's zips are fastened and secured by the Velcro® tabs.



### STEP 6

It is extremely important that when fastening the A-frame strap that it is passed OVER the brake cable. This ensures that it doesn't affect the safety of the vehicles when towing.





## STEP 7

Once the strap is safely in place over the A-frame, simply fasten the top buckles and adjust, be careful not to over tighten the straps. Place excess webbing through slides. You are now ready to tow!



## PART 1

Wipe off any dirt or grit before removing the cover to prevent dirt transfer. Remove the cover by simply reversing the process. Ensure all clips and buckles are unfastened and slowly slide the cover down the awning channels.



## PART 2

Once removed, zip the offside section and fold the cover. When folding ensure that the fleecy inner of the fabric is on the outside again to prevent any transfer of dirt from the outside of the cover. The cover can now be placed back into its storage bag ready for your next trip.



By undoing the top zip sections, your caravans front window can be exposed. To make the cover more stable in windy conditions, fix the male velcro tabs on the elasticated tension strap to the female velcro tabs on the underside of the two zip covers situated at the top of the cover.



Undo the zips at either side of the centre panel to expose the grab handles. This feature allows you to manoeuvre your van into place, as required.



The Tow Pro + allows you to access your locker box, gaining access to the gas and other items during a journey, without removing the cover (where applicable).

### NEED HELP? CALL OUR EXPERTS FOR ASSISTANCE

Office hours: Mon – Fri 9am – 5pm, Sat – Sun CLOSED

T: 01943 864 646

E: [info@specialisedcovers.com](mailto:info@specialisedcovers.com)

W: [specialisedcovers.com](http://specialisedcovers.com)